




This drawing, specifications, and concepts contained here in are the sole property of Dart Aerospace, and may not be reproduced or used in any fashion without the prior written permission of Dart Aerospace.



SECTION A-A



NOTE:
USED ON BEARING MS14101-6.

Part #	UNIT QTY	Description
-1	1	RECEIVER
-3	1	REMOVER / INSTALLER
-5	1	ALIGNMENT SEAT
-7	1	HEX HEAD CAP SCREW
-9	1	WASHER
-11	1	NUT

DART
AEROSPACE

190 S. Danebo Ave., Eugene, OR. 97402
1-800-556-4166
e-mail: sales@dartaero.com
dartaerospace.com

TITLE PORTABLE BEARING INSTALL & REMOVAL
TOOLS FOR MS14101 & MS14103

DWG NO.	RBIR4104-6	REV	CUSTOMER 1 OF 1
SCALE	1:1	DATE	2/19/2015 SHEET 1 OF 1